

works with  
**PS3™**  
& PS3 Slim



**dreamGEAR**

**iSound: The New Sound**  
www.dreamGEAR.net | www.iSound.net  
20001 S. Western Avenue, Torrance, CA 90501  
tel: 310.222.5522 :: fax: 310.222.5577

# Quad Dock Pro

Charging Dock for Four Controllers

ITEM No. - DGPS3-3811  
UPC - 8 45620 03811 4  
COLOR - Black

## PRODUCT FEATURES

The Quad Dock Pro allows you to charge up to 2 original Sony SIXAXIS™ or DUALSHOCK®3 controllers, 1 PlayStation®Move motion controller and 1 PlayStation®Move navigation controller simultaneously. All docks are designed to securely fit their respective controllers and even have cutouts for wrist straps. It also has 2 powered USB ports built-in to charge other USB powered devices including another controller, a headset or keypad. It includes a 110 / 240 Volt AC adapter to allow for charging anytime and a rubberized finish for the look and feel you will not get with any other charger.

### QUAD DOCK PRO

- Dock securely holds and charges 2 Sony original SIXAXIS™ or DUALSHOCK®3 controllers
- Dock securely holds and charges PlayStation®Move motion controller
- Dock securely holds and charges PlayStation®Move navigation controller
- Cutouts in cradles to fit PlayStation®Move controller wrist straps
- Includes 110 / 240 Volt AC Adapter
- 2 USB ports built-in (can charge additional USB powered devices including controllers, headsets, mobile phones, and other accessories)
- LED charge indicators (Blue = Fully charged, Flashing blue and red = 95% charged, Red = charging)
- **Rubberized finish**

## PRODUCT PACKAGING



## TRANSLATIONS

**PACKAGING** | FRENCH: Yes | SPANISH: Yes  
**USER GUIDE** | FRENCH: Yes | SPANISH: Yes

## SHIPPING INFORMATION

	QUANTITY	WIDTH (in.)	HEIGHT (in.)	DEPTH (in.)	CUBE (ft³)	WEIGHT (lbs.)	UPC NUMBER
MASTER	16	11.25	10.5	16.75	1.15	13.35	8 45620 03811 4
INNER	4	4	9.75	10.5	0.24	3.10	8 45620 03811 4
SINGLE	1	3.5	9.25	2.5	0.05	0.75	8 45620 03811 4



### LED Charge Indicators

Solid Blue = Fully Charged, Flashing Blue & Red = 95% Charged, Red = Charging



Charge up to 2 controllers (using USB ports)



Charge your Bluetooth® Headset



Charge your Wireless Keypad



Charge your MP3 Player



Charge your Cell Phone

DUALSHOCK®3, PlayStation®Move motion and PlayStation®Move navigation Controllers not included  
Final product, features, and packaging may vary